

## *A Technique to Try*

- Soak packing cords in Hemodent (made by Premier \*888-670-6100).
- Burnish sulcus using Ultradent Dental Infuser with Viscostat (made by Ultradent \*888-230-1420). Repeat until there is no bleeding.
- Pack #0 Ultrapack cord (made by Ultradent \*888-230-1420) completely around the preparation to the bottom of the sulcus.
- Pack #2 Ultrapack cord (made by Ultradent \*888-230-1420) completely around the preparation on top of the #0 cord.
- Let sit for 5 minutes.
- Wet cords with water from 3 way and gently remove.
- If weeping occurs, burnish again with Viscostat.
- Rinse thoroughly with water from 3 way and dry completely.
- Inject 3M ESPE Imprint 3 Light Body Impression Material around the margin. Made by 3M ESPE \*800-344-9170. While you're doing this, have your assistant fill the top and bottom of a Harmony tray (made by Practicon \*800-959-9505) with 3M ESPE Imprint 3 Heavy Body impression material. DO NOT use tray adhesive.
- Using your 3 way, blow air lightly over margin and into sulcus.
- Re-inject with light body impression material around margin, over preparation and also over the occlusal surfaces of the adjacent teeth.
- Seat tray against preparation arch and have your patient close fully into centric occlusion.
- Allow 5 minutes to set up and remove.