

## **Locator Reline and Pick Up**

**If not already in the mouth, seat the Locator abutments**

1. Place a Locator cap on each Locator abutment
2. Take a reline impression using the existing overdenture as a tray
3. After the impression is withdrawn, snap a Locator Abutment Analogue into each Black Processing Male. If the Locator did not come out with the impression send them along with the denture to the lab for processing.